I. Introduction

The PIR sensor is designed by infrared to detect the movement of humans or animals in the environment, combined with other devices, to achieve intelligent application scenes

II. Specification

Name	PIR Sensor (Zigbee)
Model	HS-PS01
Detection Distance	5 Meters
Detection Angle	150°
Battery Type	CR2450
Working Temperature	-10°C ~ 45°C
Working Humidity	10%-95% RH (No Condensation
Wireless Connection	Zigbee 3.0

III. Connect Preparation

Connect your phone to WIFI —— Smart Phone ——

WIFI Wireless Router —— Smart Host

LAN Interface LAN Interface

- Ensure that the product is within effective coverage of the smart host(Gateway) ZigBee network to ensure that the product is effectively connected to the smart host(Gateway) ZigBee network.
- Make sure the gateway is added.

IV. Download APP

Search the app store for related APP Or scan the QR code on the outer packing, download and install it. If you download APP for the first time, please click the "Registration" button to register an account; If you already have an account, click the login button.

V. Network Settings

1. Power the device on and ensure that the mobile phone has been connected to the network and has successfully added the smart gateway;
2. Open the HIP IOT app, on the "smart gateway" page, click "Add Device" button and select "PIR Sensor" on the "Select Device Type" page.
3. Using the reset needle, press the reset button for more than 5s until the network indicator flashes. Add the device according to the APP instructions.
4. Once added, you can find the device in "My Home" list.

VI. Packing List

- PIR Sensor *1
- Back Gum Paste *1
- Battery *1
- Reset Needle *1
- Product user manual *1

Please read the user manual carefully before using the product.

Zigbee PIR Sensor User Manual

1.บทนำ

เซ็นเซอร์ PIR ได้รับการออกแบบโดยอินฟราเรดเพื่อตรวจจับการเคลื่อนไหวของมนุษย์หรือสัตว์ในสิ่งแวดล้อม รวมกับอุปกรณ์อื่นๆ เพื่อให้ได้จากแอปพลิเคชันอัจฉริยะ

2. ข้อมูลจำเพาะ

Name	PIR Sensor (Zigbee)
Model	HS-PS01
Detection Distance	5 Meters
Detection Angle	150°
Battery Type	CR2450
Working Temperature	-10°C ~ 45°C
Working Humidity	10%-95% RH (No Condensation
Wireless Connection	Zigbee 3.0

3. การเตรียมการเชื่อมต่อ

เชื่อมต่ออินทัศพัทของคุณกับ WIFI —— สมาร์ทโฟน —— เราเตอร์ไร้สาย

WIFI —— Smart Host

อินเทอร์เฟซ LAN อินเทอร์เฟซ LAN

- ตรวจสอบให้แน่ใจว่าผลิตภัณฑ์อยู่ในขอบเขตที่มีประสิทธิภาพของเครือข่ายสมาร์ทโฮสต์ (เกตเวย์) ZigBee เพื่อให้แน่ใจว่าผลิตภัณฑ์เชื่อมต่อกับเครือข่ายสมาร์ทโฮสต์ (เกตเวย์) ZigBee อย่างมีประสิทธิภาพ
- ตรวจสอบให้แน่ใจว่ามีการเพิ่มเกตเวย์

4. ดาวน์โหลดแอปพลิเคชัน

ค้นหา App Store สำหรับ APP ที่เกี่ยวข้อง หรือสแกนรหัส QR บนบรรจุภัณฑ์ด้านนอก ดาวน์โหลดและติดตั้ง หากคุณดาวน์โหลดแอปเป็นครั้งแรก โปรดคลิกปุ่ม "ลงทะเบียน" เพื่อลงทะเบียนบัญชี หากคุณมีบัญชีอยู่แล้ว ให้คลิกปุ่มเข้าสู่ระบบ

5. การตั้งค่าเครือข่าย

1. เปิดอุปกรณ์และตรวจสอบให้แน่ใจว่าโทรศัพท์มือถือเชื่อมต่อกับเครือข่ายและเพิ่มสมาร์ทเกตเวย์เรียบร้อยแล้ว
2. เปิดแอป HIP IOT ในหน้า "สมาร์ทเกตเวย์" คลิกปุ่ม "เพิ่มอุปกรณ์" และเลือก "เซ็นเซอร์ PIR" ในหน้า "เลือกประเภทอุปกรณ์"
3. ใช้เข็มรีเซ็ต กดปุ่มรีเซ็ตนานกว่า 5 วินาที จนกว่าไฟแสดงเครือข่ายจะกะพริบ เพิ่มอุปกรณ์ตามคำแนะนำของแอพ
4. เมื่อเพิ่มแล้ว คุณจะพบอุปกรณ์ในรายการ "บ้านของฉัน"

6. รายการบรรจุภัณฑ์

- เซนเซอร์ตรวจจับการเคลื่อนไหว*1
- เทปติดอุปกรณ์ *1
- แบตเตอรี่ *1
- เข็มรีเซ็ต *1
- คู่มือการใช้งาน *1

โปรดอ่านคู่มือผู้ใช้อย่างละเอียดก่อนใช้ผลิตภัณฑ์

Zigbee PIR Sensor คู่มือการใช้งาน